

PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

HINT:

Inspect the "Fuse" and "Relay" before confirming the suspected areas as shown in the chart below.

Inspect each malfunction circuit in numerical order for the corresponding symptom.

If the malfunction still exists even after checking and confirming that all the circuits are normal, replace the ECM.

Symptom	Suspected Area	See page
Main switch cannot be turned ON. (Cruise indicator light in combination meter does not come on.)	3. Cruise control switch circuit 4. CRUISE main indicator light circuit 5. ECM	05-2160 05-2165 10-24
Vehicle speed setting cannot be done. (Although indicator light in combination meter comes on when the main switch is turned ON, it goes off when vehicle speed is set.)	1. Cruise control switch circuit 2. ECM	05-2160 10-24
Setting cannot be done. (Indicator light in combination meter comes on when the main switch is turned ON and they remain ON while setting.)	1. Cruise control switch circuit 2. Stop lamp switch circuit 3. Park/neutral position switch circuit 4. Transmission control switch circuit 5. Combination meter system 6. ECM	05-2160 05-2155 05-1036 05-922 05-1109 05-981 05-1868 10-24
While the vehicle is driven with cruise control, the set control is cancelled. (Indicator light and CRUISE remain ON.)	1. Cruise control switch circuit 2. Vehicle speed sensor circuit 3. Stop lamp switch circuit 4. CRUISE main indicator light circuit 5. Park/neutral position switch circuit 6. ECM	05-2160 05-578 05-216 05-2155 05-2165 05-1036 05-922 10-24
Hunting (Speed is not constant.)	1. Vehicle speed sensor circuit 2. ECM	05-578 05-216 10-24
Setting cannot be cancelled. (When Coast, Acceleration, Resume, Set speed change and Control switch are operated.)	1. Cruise control switch circuit 2. ECM	05-2160 10-24
DTC is not output, or is output when should not be.	1. Diagnosis circuit 2. ECM	05-2166 10-24
CRUISE MAIN indicator light does not come on.	1. Cruise control switch circuit 2. CRUISE main indicator light circuit 3. ECM 4. Combination meter assy	05-2160 05-2165 10-24 71-18