

<b>DTC</b>	<b>B0111/44</b>	<b>OPEN IN SIDE SQUIB (RH) CIRCUIT</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

The side squib RH circuit consists of the airbag sensor assy center and the separate type front seat back assy (side squib RH).

The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B0111/44 is recorded when an open circuit is detected in the side squib RH circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B0111/44	<ul style="list-style-type: none"> <li>• Open circuit in SFR+ wire harness or SFR- wire harness of side squib RH</li> <li>• Side squib (RH) malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Separate type front seat back assy (Side squib RH)</li> <li>• Airbag sensor assy center</li> <li>• Floor wire</li> </ul>

## WIRING DIAGRAM

see page 05-1263 .

## INSPECTION PROCEDURE

<b>1</b>	<b>CHECK FLOOR WIRE(SIDE SQUIB RH CIRCUIT)</b>
----------	--



- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Disconnect the connectors from the airbag sensor assy center and the separate type front seat back assy (side squib RH).
- Measure the resistance according to the value(s) in the table below.

### Standard:


Tester connection	Condition	Specified condition
S19-1 (SFR+) - S19-2 (SFR-)	Always	Below 1 $\Omega$

**NG**

**REPAIR OR REPLACE FLOOR WIRE**

**OK**

## 2 CHECK AIR BAG SENSOR ASSY CENTER



- Connect the connector to the airbag sensor assy center.
- Using a service wire, connect S19-1 (SFR+) and S19-2 (SFR-) of connector "C".

### NOTICE:

**Do not forcibly insert a service wire into the terminals of the connector when connecting.**

- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1215 ).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-1215 ).

### OK:

**DTC B0111/44 is not output.**

### HINT:

Codes other than code B0111/44 may be output at this time, but they are not related to this check.


**NG**

**REPLACE AIR BAG SENSOR ASSY CENTER  
(SEE PAGE 60-53 )**

**OK**

## 3

## CHECK SEPARATE TYPE FRONT SEAT BACK ASSY(SIDE SQUIB RH)



- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the service wire from connector "C".
- (d) Connect the connector to the separate type front seat back assy (side squib RH).
- (e) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in memory (see page 05-1215 ).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (see page 05-1215 ).

**OK:****DTC B0111/44 is not output.****HINT:**

Codes other than code B0111/44 may be output at this time, but they are not related to this check.

**NG**

**REPLACE SEPARATE TYPE FRONT SEAT BACK ASSY (SEE PAGE 72-11, 72-19)**

**OK****USE SIMULATION METHOD TO CHECK****HINT:**

- Before performing the simulation method, check that the airbag sensor assy center is in check mode (see page 05-1218 ).
- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1218 ).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-1218 ).