

WIPER AND WASHER SYSTEM

6605A-09

PRECAUTION

1. PRECAUTION OF WASHER NOZZLE ADJUSTMENT

- (a) Do not clean or adjust the washer nozzle with a safety pin, etc. because;
 - (1) the washer nozzle tip is made of resin and could be damaged.
 - (2) adjustment is not necessary because the washer nozzle is spray type.
- (b) In case the washer nozzle is clogged with wax, etc., remove it and clean the nozzle hole with a soft resin brush, etc.