

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All power seat functions do not operate	1. POWER M-fuse 2. Wire harness	72-1 -
Only slide operation function does not operate	1. Front power seat switch 2. Slide motor 3. Wire harness	72-6 72-6 -
Only front vertical operation function does not operate (driver's seat only)	1. Front power seat switch 2. Front vertical motor 3. Wire harness	72-6 72-6 -
Only rear vertical operation function does not operate (driver's seat only)	1. Front power seat switch 2. Rear vertical motor 3. Wire harness	72-6 72-6 -
Only reclining operation function does not operate	1. Front power seat switch 2. Reclining motor 3. Wire harness	72-6 72-6 -
Only lumbar support operation function does not operate (driver's seat only)	1. Power seat switch assy (Lumbar support) 2. Lumbar support adjuster motor 3. Wire harness	72-6 72-6 -