


OVERHAUL

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).

1. REMOVE DECK BOARD SUB-ASSY (See page 76-21)



2. REMOVE REAR SEAT TRACK BRACKET COVER OUTER

- (a) Using a screwdriver, disengage the 4 claws remove the bracket cover.

HINT:

Tape the screwdriver tip before use.

3. REMOVE REAR SEAT TRACK BRACKET COVER INNER

HINT:

Use the same procedures described for the bracket cover outer.

4. REMOVE REAR NO.1 SEAT ASSY RH

- (a) Using a clip remover, remove the 5 clips.


HINT:

Tape the clip remover tip before use.

- (b) Remove the bolt holding the fold seat stopper band on the vehicle side.
 (c) Remove the 2 headrests.
 (d) Remove the 5 bolts and seat.

5. REMOVE TONNEAU COVER HOOK HOLDER

- (a) Remove the 2 screws and 2 holders.




6. REMOVE REAR SEATBACK COVER RH

- (a) Using a screwdriver, disengage the 4 claws and remove the seatback cover.


HINT:

Tape the screwdriver tip before use.



7. REMOVE REAR SEATBACK BOARD CARPET ASSY RH

- (a) Remove the 6 clips and seatback board carpet.


**8. REMOVE RECLINING COVER PROTECTOR LH**

- (a) Using a clip remover, remove the clip.


HINT:

Tape the clip remover tip before use.

- (b) Remove the screw and reclining cover protector by pulling out the protector in the direction indicated by the arrow in the illustration.

**9. REMOVE CENTER SEAT HINGE COVER UPPER LH**

- (a) Remove the screw.
- (b) Using a screwdriver, remove the claw and hinge cover by pulling out the cover in the direction indicated by the arrow in the illustration.

**10. REMOVE REAR SEATBACK ASSY CENTER**

- (a) Remove the screw.
- (b) Using a torx® socket wrench (T45), remove the torx® bolt.
- (c) Remove the 3 bolts and seatback.

11. REMOVE RECLINING COVER PROTECTOR RH

- (a) Using a clip remover, remove the clip.

HINT:

Tape the clip remover tip before use.

- (b) Remove the screw and reclining cover protector.

12. REMOVE REAR SEATBACK MOULDING LH


- (a) Using a torx® socket wrench (T40), remove the torx® bolt and center back hinge.
- (b) Using a torx® socket wrench (T40), remove the torx® bolt and rear seat cushion spring No. 2.
- (c) Remove the 3 screws and moulding.

13. REMOVE REAR SEATBACK MOULDING RH

- (a) Using a torx® socket wrench (T40), remove the torx® bolt and center back hinge.
- (b) Remove the 3 screws and moulding.

14. REMOVE REAR SEAT ARMREST ASSY CENTER


- (a) Using a torx® socket wrench (T45), remove the 2 torx® bolts and armrest.

**15. REMOVE NO.1 SEATBACK COVER**


- (a) Remove the 2 headrest supports.
- (b) Disengage the claws and remove the seatback cover.

16. REMOVE NO.2 CENTER SEATBACK COVER

- (a) Remove the 2 screws and seatback cover.

**17. REMOVE REAR SEAT CUSHION MOULDING RH**

- (a) Remove the 2 screws.
- (b) Remove the moulding by pulling it out in the direction indicated by the arrow in the illustration.

**18. REMOVE REAR SEAT CUSHION MOULDING REAR RH**

- (a) Remove the 2 screws.
- (b) Using a screwdriver, disengage the 3 claws and remove the moulding.

HINT:


Tape the screwdriver tip before use.

19. REMOVE REAR SEAT CUSHION ASSY RH

- (a) Using a torx® socket wrench (T45), remove the 2 torx® bolts.
- (b) Remove the 2 bolts and seat cushion.

20. REMOVE SEPARATE TYPE REAR SEAT CUSHION COVER

- (a) Disengage the hook and remove the cushion cover together with the pad from the cushion frame.
- (b) Remove the hog rings and cushion cover.




21. REMOVE REAR SEAT LOCK CONTROL LEVER SUB-ASSY RH

- (a) Using a screwdriver, disengage the 2 claws and remove the control lever cover.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 2 screws.
(c) Disconnect the reclining control cable and remove the control lever.




22. REMOVE REAR SEATBACK LOCK BEZEL UPPER

- (a) Using a screwdriver, disengage the 2 claws and 2 hooks.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the shoulder belt cover by pulling it out in the direction indicated by the arrow in the illustration.




23. REMOVE SEPARATE TYPE REAR SEATBACK COVER

- (a) Remove the 2 headrest supports.
(b) Using a clip remover, remove the 2 clips.
(c) Disengage the hook and remove the seatback cover together with the pad from the seatback frame.
(d) Remove the hog rings and seatback cover.

24. REMOVE REAR SEAT BELT ASSY OUTER CENTER (See page 61-15)

25. REMOVE REAR SEATBACK FRAME ASSY RH

- (a) Using a torx® socket wrench (T45), remove the 2 torx® bolts.
(b) Remove the 2 bolts and seatback frame.



26. REMOVE REAR SEAT SHOULDER BELT COVER


- (a) Disengage the 2 claws and remove the belt cover by pulling it out in the direction indicated by the arrow in the illustration.

27. REMOVE FOLD SEAT STOPPER BAND ASSY NO.1

- (a) Remove the bolt and stopper band.

28. DISCONNECT REAR SEAT RECLINING CONTROL NO. 2 CABLE

29. REMOVE REAR SEAT BELT ASSY INNER (See page 61-15)

**30. REMOVE REAR SEAT RECLINING COVER INNER RH**

- (a) Remove the screw and the reclining cover in the direction indicated by the arrow in the illustration.

31. REMOVE SEAT TRACK STOP PLATE RH

- (a) Remove the 2 nuts and the seat track stop plate.

32. REMOVE RECLINING CONTROL LINK SUB-ASSY RH

- (a) Remove the bolt, 4 nuts and reclining control link.

33. REMOVE REAR SEATBACK FRAME SUB-ASSY LOWER RH


- (a) Using a torx® socket wrenches (T40), remove the 3 torx® bolts.
 (b) Using a torx® socket wrenches (T55), remove the 2 torx® bolts and seatback frame.

34. REMOVE FOLD SEAT CUSHION FRAME NO.1

- (a) Remove the 2 nuts and cushion frame.

35. REMOVE FOLD SEAT CUSHION FRAME NO.2

- (a) Remove the 2 nuts and cushion frame.

**36. REMOVE REAR SEAT TRACK ADJUSTING HANDLE**

- (a) Using a screwdriver, push down the handle stopper to disengage the claw with the slide rail in the frontmost position. Remove the track adjusting handle.

37. INSTALL FOLD SEAT CUSHION FRAME NO.1

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

38. INSTALL FOLD SEAT CUSHION FRAME NO.2

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

39. INSTALL REAR SEATBACK FRAME SUB-ASSY LOWER RH**(a) Outer side:**

Using a torx® socket wrench (T40), install the seatback frame lower to the fold seat cushion frame with the 3 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

(b) Inner side:

Using a torx® socket wrench (T55), install the seatback frame lower to the fold seat cushion frame with the 2 torx® bolts.

Torque: 120 N·m (1224 kgf·cm, 89 ft·lbf)

40. INSTALL SEAT TRACK STOP PLATE RH**(a) Install the seat track stop plate with the 2 nuts.**

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

41. INSTALL RECLINING CONTROL LINK SUB-ASSY RH**(a) Install the control link with the bolt and 4 nuts.**

Torque:

21 N·m (214 kgf·cm, 15 ft·lbf) for bolt

42 N·m (428 kgf·cm, 31 ft·lbf) for nut

42. INSTALL REAR SEATBACK FRAME ASSY RH**(a) Install the seatback frame with the 4 bolts.**


Torque:

42 N·m (428 kgf·cm, 31 ft·lbf) for outside

55 N·m (561 kgf·cm, 41 ft·lbf) for inside

43. INSTALL REAR SEAT BELT ASSY INNER (See page 61-15)**44. INSTALL REAR SEAT BELT ASSY OUTER CENTER (See page 61-15)****45. INSTALL FOLD SEAT STOPPER BAND ASSY NO.1****(a) Install the stopper band with the bolt.**

Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)

**46. INSTALL SEPARATE TYPE REAR SEATBACK COVER****(a) Using hog ring pliers, install the seatback cover to the seatback pad with new hog rings.****(b) Install the seatback cover to the seatback frame.****NOTICE:**

- **Be careful not to damage the cover.**
 - **When installing the hog rings, take care to prevent wrinkles as much as possible.**
- (c) Install the 2 headrest supports.**

47. INSTALL SEPARATE TYPE REAR SEAT CUSHION COVER**(a) Using hog ring pliers, install the cushion cover to the cushion pad with new hog rings.****NOTICE:**

- **Be careful not to damage the cover.**
 - **When installing the hog rings, take care to prevent wrinkles as much as possible.**
- (b) Install the seat cushion cover to the seat cushion frame.**

48. INSTALL REAR SEAT CUSHION ASSY RH

- (a) Using a torx® socket wrench (T45), install the seat cushion with the 2 torx® bolts.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf) for hinge side

- (b) Install the seat cushion assy with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf) for cushion side

49. INSTALL REAR SEAT ARMREST ASSY CENTER

- (a) Using a torx® socket wrench (T45), install the armrest assy with the 2 torx® bolts.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

50. INSTALL REAR SEATBACK MOULDING LH

- (a) Install the moulding with the 3 screws.

- (b) Using a torx® socket wrench (T40), install the center back hinge with the torx® bolt.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

- (c) Using a torx® socket wrench (T40), install the rear seat cushion spring No. 2 with the torx® bolt.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

51. INSTALL REAR SEATBACK MOULDING RH

- (a) Install the moulding with the 3 screws.

- (b) Using a torx® socket wrench (T40), install the center back hinge with the torx® bolt.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

52. INSTALL REAR SEATBACK ASSY CENTER

- (a) Install the screw.

- (b) Using a torx® socket wrench (T45), install the seatback assy center with the torx® bolt.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

- (c) Install the seatback assy with the 3 bolts.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

53. INSTALL REAR NO.1 SEAT ASSY RH

- (a) Place the seat in the cabin.

- (b) Install the seat with the 5 bolts.

Torque: 36.7 N·m (375 kgf·cm, ft·lbf)

- (c) Install the bolt onto the fold seat stopper band on the vehicle side.

Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)

- (d) Install the 2 headrests.

- (e) When sliding the seat, check that both sides of the adjuster lock simultaneously.

HINT:

Check that the seat adjuster locks.