AUTOMATIC TRANSAXLE ASSY (U151E/U151F)

4012C-02

COMPONENTS




Front Drive Shaft Assy RH
◆ Front Drive Shaft RH Hole Snap Ring
8.4 (86, 74 in.·lbf)
13 (133, 10)
8.4 (86, 74 in.·lbf)
Wire Harness Clamp
12 (122, 9)
Transmission Control Cable Bracket No.2
34 (350, 25)
Transfer Stiffener Plate RH
Wire Harness Clamp
69 (700, 51)
46 (470, 34)
64 (650, 47)
Transfer Assy
41 (418, 30)
Torque Converter Clutch Assy
x 6
37 (377, 27)
5.5 (56, 49 in.·lbf)
7.8 (80, 69 in.·lbf)
69 (700, 51)
Transmission Oil Filler tube sub-assy
Flywheel Housing Under Cover
Front Drive Shaft Assy LH
◆ O-Ring
Automatic transmission Oil cooler tube clamp
Transmission Oil Level Gauge sub-assy
5.4 (55, 48 in.·lbf)
Transmission Control Cable Bracket No.1
◆ Front Drive Shaft LH Hole Snap Ring
9.8 (100, 87 in.·lbf)
12 (122, 9)
Oil Cooler Outlet Tube No.1
Engine Mounting Bracket No.1
Starter Assy
Oil Cooler Inlet Tube No.1
64 (653, 47)
34 (347, 25)
N·m (kgf·cm, ft·lbf) : Specified torque
◆Non-reusable part
37 (377, 27)
C
D31756