


**COWL TOP TO APRON BRACE (ASSY)**


REPLACEMENT




F16755A

REMOVAL

[RH]





[LH]



F16755

**INSTALLATION**

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.

**[RH]****[LH]**

F16756

10 mm (0.39 in.)

20 mm (0.79 in.)