

WIRELESS DOOR LOCK CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

05260-02

HINT:

Troubleshoot in accordance with the procedure on the following pages.

1 VEHICLE BROUGHT TO WORKSHOP



2 CUSTOMER PROBLEM ANALYSIS AND SYMPTOM CHECK (See page 05-1962)



3 INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Check that there is no abnormality in the communication system by inspecting the communication function of the body multiplex communication system with the hand-held tester.
- (1) (ECU unconnected, communication line abnormal) Without code output, proceed to A.
 - (2) (ECU unconnected, communication line abnormal) With code output, proceed to B.

B

GO TO BODY MULTIPLEX COMMUNICATION SECTION (See page 05-2040)

A

4 CHECK DIAGNOSTIC TROUBLE CODE (See page 05-1964)

- (a) Check a DTC and note it down if a code is output.
- (b) Delete the DTC.
- (c) Check if the DTC will be output once again, when the problem symptom is simulated based on the noted code.
- (1) Without an output of the code, proceed to A.
 - (2) With an output of the code, proceed to B.

B

Go to step 7

A

5 PROBLEM SYMPTOMS TABLE (See page 05-1967)

- (a) Without applicable symptoms, proceed to A.
- (b) With applicable symptoms, proceed to B.

B

Go to step 7

A

6	PERFORM TROUBLESHOOTING IN THE FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM
----------	--

- (a) Pre-check (See page [05-1963](#)).
- (1) Inspection with the hand-held tester (ECU DATA MONITOR).
 - (2) Inspection with the hand-held tester (ACTIVE TEST).
- (b) Terminals of ECU (See page [05-1966](#)).



7	ADJUSTMENT, REPAIR OR REPLACEMENT
----------	--



END
