


## ACCELERATOR PEDAL ROD ASSY (3MZ-FE) REPLACEMENT

100MJ-01



### 1. REMOVE ACCELERATOR PEDAL ROD ASSY

- (a) Disconnect the accelerator pedal position sensor connector.
- (b) Remove the 2 bolts and pedal rod.

### 2. INSTALL ACCELERATOR PEDAL ROD ASSY

- (a) Install the pedal rod with the 2 bolts.  
**Torque: 4.9 N·m (50 kgf·cm, 43 in·lbf)**
- (b) Connect the accelerator pedal position sensor connector.