


FUEL PUMP ASSY (2AZ-FE)

COMPONENTS

1111T-01

w/ Rear No. 2 Seat




N·m (kgf·cm, ft·lbf) : Specified torque

P


A92780

w/o Rear No. 2 Seat




N·m (kgf·cm, ft·lbf) : Specified torque

A92781



◆ Non-reusable part_p

A92785



A81632