



# FUEL TANK ASSY (3MZ-FE)

## COMPONENTS

1111Y-01




w/o Rear No. 2 Seat:



N·m (kgf·cm, ft·lbf) : Specified torque


P


A92690



◆ Non-reusable part<sub>p</sub>

A92785






N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A81215



N·m (kgf·cm, ft·lbf) : Specified torque

P ♦ Non-reusable part

A81216