



PARTIAL ENGINE ASSY (3MZ-FE) COMPONENTS

141PI-02







H

N·m (kgf·cm, ft·lbf) : Specified torque


A91356



A91357



A91358




H

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A91359




H

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A91361




H


N·m (kgf·cm, ft·lbf) : Specified torque


◆ Non-reusable part

A91363



A81803






N·m (kgf·cm, ft·lbf): Specified torque

◆ Non-reusable part

P


A78304





N·m (kgf·cm, ft·lbf) : Specified torque

P

A78305






LH Bank

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A78308



A78309