


# STEERING PAD SWITCH LH REPLACEMENT

67166-01


## HINT:

- COMPONENTS: See page 67-2
  - Installation is in the reverse order of removal.
1. **PRECAUTION (SEE PAGE 60-1 )**
  2. **SEPARATE BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1 )**
  3. **REMOVE STEERING WHEEL COVER LOWER NO.2 (SEE PAGE 50-8 )**
  4. **REMOVE STEERING WHEEL COVER LOWER NO.3 (SEE PAGE 50-8 )**
  5. **REMOVE HORN BUTTON ASSY (SEE PAGE 50-8 )**



## 6. REMOVE STEERING PAD SWITCH LH

- (a) Disconnect the connector.
- (b) Disconnect the connector of cruise control main switch.
- (c) Remove the screw.



- (d) Release the 2 pin fittings and remove the steering pad switch LH.

7. **INSTALL HORN BUTTON ASSY (SEE PAGE 60-1 1)**
8. **CONNECT BATTERY NEGATIVE TERMINAL**
9. **INSPECT HORN BUTTON ASSY (SEE PAGE 50-8 )**
10. **INSPECT SRS WARNING LIGHT (SEE PAGE 05-1207 )**