

# AUDIO & VISUAL SYSTEM

6715Q-01

## PRECAUTION

### 1. OBSERVE HANDLING AND OPERATIONAL PRECAUTIONS

- (a) Explain to the customer that when the negative terminal is disconnected from the battery, the AM/FM channel presets in the radio receiver are cleared. If necessary, make a note of the recorded channel information before the negative terminal is disconnected, then reset the information after the negative terminal is reconnected.
- (b) The removal/installation of the radio receiver should be performed after all cassette tapes and audio CDs are ejected from the radio receiver.

#### HINT:

If a cassette tape or audio CD cannot be ejected due to malfunction of the radio receiver, do not attempt to remove it forcefully. Bring the vehicle to the repair plant.

- (c) Fasten the earth bolt securely when the antenna cord is removed or installed.

#### HINT:

Failure to fasten the earth bolt securely causes noise when receiving radio waves.

- (d) Do not touch the cone paper of the speaker.