

WIRELESS DOOR LOCK CONTROL SYSTEM

7302E-02

PRECAUTION

HINT:

The switch described in this text indicates the switch for transmitting signals, which is built in the door control transmitter.

1. NOTE WHEN CHECKING

- (a) The wireless door lock remote control function operates only when the following 4 conditions are satisfied.
 - (1) All the doors are closed.
 - (2) No key is inserted in the ignition key cylinder.
 - (3) The power door lock operates normally.
 - (4) The receiving function is not cancelled by the security function.
- (b) The wireless door lock remote control function operational area.
 - (1) The operational area differs depending on the operator and the way the transmitter is held.
 - (2) In some places, the operational area will be reduced due to the vehicle body shape and the influence of the surrounding environment, or the remote control function will only operate partially.
 - (3) Because the transmitter uses faint electric waves, strong electric waves or noise in the frequency used may reduce the operational area or the remote control may not function.
 - (4) When the battery weakens, the operational area is reduced or the remote control may not be operated.

HINT:

If the door control transmitter has been left in a place that is exposed to the direct sunlight, such as on the instrument panel, it may cause the battery to weaken or other trouble.