

LUGGAGE COMPARTMENT DOOR GARNISH SUB-ASSY OUTSIDE

76027-07

REPLACEMENT

1. REMOVE BACK WINDOW PANEL TRIM UPPER (See page 75-20)
2. REMOVE BACK DOOR TRIM COVER RH (See page 75-20)
3. REMOVE BACK DOOR TRIM COVER LH (See page 75-20)
4. REMOVE BACK DOOR TRIM PANEL ASSY (See page 75-20)
5. REMOVE REAR SPOILER (W/ REAR SPOILER) (See page 75-20)
6. REMOVE BACK DOOR LOCK ASSY (See page 75-20)
7. REMOVE BACK DOOR HANDLE ASSY OUTSIDE (See page 75-20)
8. REMOVE LUGGAGE COMPARTMENT DOOR GARNISH SUB-ASSY OUTSIDE
 - (a) Remove the screws and the 2 licence plate lights.
 - (b) Remove the nut and garnish.
9. INSTALL LUGGAGE COMPARTMENT DOOR NAME PLATE NO.1
 - (a) Using white gasoline, clean the garnish installation surface.
 - (b) Using a heat light, heat the garnish and name plate to 20 to 30°C (68 to 86°F).
 - (c) Install the name plate.

NOTICE:

Do not heat the garnish and name plate excessively.