

2005 HIGHLANDER ELECTRICAL WIRING DIAGRAM

| | Section Code | Page |
|---|--------------|------|
| INTRODUCTION | A | 2 |
| HOW TO USE THIS MANUAL | B | 3 |
| TROUBLESHOOTING | C | 12 |
| ABBREVIATIONS | D | 17 |
| GLOSSARY OF TERMS AND SYMBOLS | E | 18 |
| RELAY LOCATIONS | F | 20 |
| ELECTRICAL WIRING ROUTING | G | 38 |
| SYSTEM CIRCUITS | H | 60 |
| GROUND POINT | I | 314 |
| POWER SOURCE (Current Flow Chart) | J | 322 |
| CONNECTOR LIST | K | 330 |
| PART NUMBER OF CONNECTORS | L | 342 |
| OVERALL ELECTRICAL WIRING DIAGRAM . | M | 346 |