


CD SOUND SKIPS

INSPECTION PROCEDURE

1 DISC CLEANING



(a) Disc cleaning

- (1) If the disc gets dirty, clean the disc by wiping the surface from the center to outside in a radial direction with a soft cloth.

NOTICE:

Do not use a conventional record cleaner or anti-static preservative.

OK: Malfunction disappears.

OK

DISC DIRTY

NG

2 REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the CD with another and recheck.

- (1) Replace the CD with another normal one to see if the same trouble occurs again.

OK: Malfunction disappears.

OK

CD FAULTY

NG

3 CHECK WHEN THIS HAPPENS

(a) Check when this happens.

- (1) Check under what conditions (places) noise occurs.

OK: Driving on a bumpy road.

OK

Go to step 5

NG

4 COMPARE IT WITH ANOTHER CAR OF SAME MODEL

(a) Compare it with another vehicle of the same model.

- (1) Compare it with the vehicle of the same type which does not have a trouble to see if there is any difference in the CD sound.

OK: No difference found.

OK

SETTING

NG

5 CHECK OF RADIO RECEIVER ASSEMBLY INSTALLATION

- (a) Check the radio receiver assembly installation condition.
(1) Check that the radio receiver assembly is installed properly.

OK: Installed properly.

NG

INSTALL THE RADIO RECEIVER ASSEMBLY PROPERLY

OK

6 DID TEMPERATURE IN CABIN CHANGE RAPIDLY?

- (a) Did the temperature in the cabin change rapidly?
(1) Check whether or not the rapid temperature change occurred in the cabin.

OK: The rapid temperature change occurred.

Reference:

The rapid temperature change creates condensation inside the CD player, which may prevent the CD from being played.

NG

**REPLACE RADIO RECEIVER ASSY
(SEE PAGE 67-6)**

OK

CONDENSATION DUE TO TEMPERATURE CHANGE (LEAVE IT AS IT IS FOR A WHILE BEFORE USING)