


M OVERALL ELECTRICAL WIRING DIAGRAM

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

HOW TO READ THIS SECTION



[A] : System Title


[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black W = White BR = Brown
 L = Blue V = Violet SB = Sky Blue
 R = Red G = Green LG = Light Green
 P = Pink Y = Yellow GR = Gray
 O = Orange

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y




[C] : The position of the parts is the same as shown in the wiring diagram and wire routing.


[D] : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left



Female



Male


The numbering system for the overall wiring diagram is the same as above

[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : ① Indicates Relay Block No.1


[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



[G] : Indicates related system.

[H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗). Outside numerals are pin numbers.



[I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[J] : Indicates a shielded cable.



[K] : Indicates and located on ground point.

[L] : The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
Air Conditioning (Automatic A/C)	34-2	Light Auto Turn Off System	26-2
Air Conditioning (Manual A/C)	35-2	Mirror Heater	25-2
Audio System (6 Speaker)	28-2	Moon Roof	20-2
Audio System (8 Speaker)	29-2	Multiplex Communication System (BEAN Bus)	20-3
Automatic Glare-Resistant EC Mirror	20-2	Multiplex Communication System (CAN)	15-10
Automatic Light Control	12-3	Navigation System	30-2
Back-Up Light	9-4	Power Outlet (110V)	27-3
Charging	1-5	Power Outlet (12V)	27-2
Cigarette Lighter	27-2	Power Seat (Driver's Seat)	21-2
Combination Meter	31-2	Power Seat (Front Passenger's Seat)	21-3
Cruise Control (2AZ-FE)	3-11	Power Source	1~36-1
Cruise Control (3MZ-FE)	2-14	Power Window	17-2
Door Lock Control	18-2	Radiator Fan and Condenser Fan (2AZ-FE)	33-2
Electronically Controlled Transmission and A/T Indicator (2AZ-FE)	14-2	Radiator Fan and Condenser Fan (3MZ-FE)	32-2
Electronically Controlled Transmission and A/T Indicator (3MZ-FE)	13-2	Rear Heater	36-2
Engine Control (2AZ-FE)	3-2	Rear Window Defogger	25-3
Engine Control (3MZ-FE)	2-2	Rear Wiper and Washer	23-3
Engine Immobilizer System	4-2	Remote Control Mirror	24-3
Front Deicer	25-2	Seat Belt Warning	26-3
Front Fog Light	12-2	Seat Heater	22-2
Front Wiper and Washer	23-2	Shift Lock	24-2
Garage Door Opener	10-2	SRS	16-2
Headlight (w/ Daytime Running Light)	5-2	Starting	1-2
Headlight (w/o Daytime Running Light)	6-2	Stop Light	9-2
Horn	8-4	Taillight	7-2
Ignition	1-2	Theft Deterrent System	19-2
Illumination	11-2	Tire Pressure Warning System	15-3
Interior Light	10-2	Trailer Towing	22-3
Key Reminder	26-3	Turn Signal and Hazard Warning Light	8-2
		VSC	15-3
		Wireless Door Lock Control	18-8